HALO

CLEAN BOOST

User Manual

ego SONORO

Thank you and congratulation
on you're choice of
HALO clean boost pedal effect.

The **HALO** clean boost is an pedal effect that
increase the output signal level.
By rotating the knob you can increase the output signal level
without any modification of signal structure.

Little pedals, big sound!

CONNECT AND GO!!

Using you're **HALO clean** boost.
Insert 9V alkaline battery or connect the pedal to the power supplies (not included)
This pedal accept 9 Volt DC (see thecnical specification).
Plug you're guitar into the INPUT jack and run a lead from the OUTPUT jack into you're amp.
Adjust the VOLUME setting until you've found the sound you're looking for.

VOLUME adjusts the overall output level sent to you're amp.

DESCRIPTION

1. INPUT Jack

This jack accepts signal coming from a guitar, some other electric or electronics musical instruments and from another effects pedals. The INPUT Jack also serves as the power switch. Power is turned on whenever a plug is insert on the INPUT jack and is turned OFF when the plug is disconnected. To prolong the life of the battery, be sure to disconnect the plug from the input jack when not using the unit.

2. AC Adaptor jack

Accepts connection from an AC adaptor. By using an AC adaptor you can play without being concerned about how much battery power you have left.

IF YOU'RE GOING TO USE AN AC ADAPTOR, BE SURE TO FOLLOW THE VOLTAGE AND CONNECTION SPECIFICATION.

3. OUTPUT Jack

The Output jack is used to connect the unit to amplifier or other device.

4. LED Indicator

This LED shows whether the effect is ON/OFF and also as battery check indicator. The indicator lights when an effect is ON.
If this indicator goes dim or no longer lights while the effect is ON, the battery is near exhaustion and should be replaced.

5. Footswitch

This switch turns the effect ON/OFF.

REPLACE THE BATTERY

When the indicator goes dim or no longer lights while an effect is on, it means that the battery is nearly dead and must be replaced. Battery should always be installed or replaced before connecting any other devices. This way you can prevent malfunction and/or damage to speakers or other devices.
Before connecting this unit to other devices, turn off the power to all units. This will help prevent malfunction and/or damage to speakers or other devices. Replace the battery following the indication below.

1. BOTTOM SCREWS

Before to replace the battery need to remove the screws on the bottom with a screwier.

Remove the old battery from the battery housing and remove the snap cord connected to it.

Connect the snap cord to the new battery and place the battery inside the battery housing.
Be sure to carefully observe the battery's polarity.

Insert the screws into the holes and tight their with a screwier.

To prolong the life of the battery, be sure to disconnect the plug from the input jack when not using the unit.

TECHNICAL SPECIFICATIONS:

Input Impedance	1M ohm
Output Impedance	1K ohm
Power supply	9V DC
Minimum Power supply Voltage	8V DC
Maximum Power supply Voltage	13V DC
Current Draw @ 9V DC	6,0 mA
Battery Type	9V battery 6F22 Alkaline
Controls	On/Off, Volume
Gain	30dB
External connectors	Input Jack. Output Jack, 9V DC Jack (center pin negative)
Switching method	True by-pass
Depth	96 mm
Width	135 mm
Height	45 mm
Weight (battery not included)	560 g

CLEAN BOOST

WARRANTY CONDITION

Synthesis offer a 2 year warranty on all our products. On presence of malfunction, please contact our technical support at **tech@egosonoro.com** before to sending us the products for repair.
When the product has been sent to us at sender's cost, we will repair you-re product and will send back to you, shipping cost not included. The product need to be accompanied by a copy of you're receipt, serial number, return address, phone number, e-mail address and a brief explanation of the problem.

The warranty is lost if the product has been damaged by alteration, misuse, accident or neglect or if the product has been repaired or serviced by personnel not authorized by Synthesis company.

MAINTENANCE

Clean the unit with a softslightly dampened lint-free cloth. Don't use any cleaning agents as they may have a corrosive effect.

ENVIROMENTAL INFORMATION

Your set consists of material which can be recycled if disassembled by a specialized company. Please observe the local regulations regarding the disposal of packing materials, exhausted batteries and old equipments.

RoHS COMPLIANT 2002 / 95 / EC

EGOSONORO

PEDALS EFFECT

SYNTHESIS

Via Vanvitelli 14/a - 62010 MORROVALLE
MACERATA - ITALY
www.egosonoro.com

© 2010 Synthesis

In order to continually improve the design, quality and performance of our products and to make use of the best available materials at all time, SYNTHESIS reserves the right to change specifications without notice.

© 2010 Synthesis. All right reserved. Further technical details, images, products review and company history are available from Egosonoro web site, **www.egosonoro.com**

PRODOTTO FATTO A MANO NELLA REPUBBLICA ITALIANA

MADE IN ITALY